



User Manual

Wired Keyboard with numpad on the left (or Left-handed wired keyboard)

Set up:

1. Connect the USB cable (included within the keyboard box) to the USB of the PC and the other port (Android mini USB) on the keyboard lateral side (next to the 2 USB ports).
2. Please wait until keyboard software installation is done
3. Keyboard is recognized and ready to use.

The keyboard operates as a standard AZERTY FR keyboard.

Additional functions:

1. USB Hub: The keyboard provides 2 USBs (2.0) on the lateral side that can be used to connect peripherals (mouse and USB keys) or other devices such as mobiles or external battery for charging.
2. F1 to F9 activation: Keep Fn key pressed and activate once F1 to F9 keys to enable the relevant shortcut.

FN+F1 : Home page – Default web browser
FN+F2 : E-Mail
FN+F3 : Music application
FN+F4 : Play/Pause
FN+F5 : Top (web navigation or document)
FN+F6 : Bottom (web navigation or document)
FN+F7 : Mute
FN+F8 : Decrease audio volume
FN+F9 : Increase audio volume

Specifications :

Keyboard :

Compatibility : Win7/8/10, Vista, XP, 2003, 2000
Connexion : USB/Android mini USB
Cable : 1.35m
Dimensions : 465 x 138 x 27 mm
Weight : 480 gr

Keyboard packaging:

Box: Carton
Keyboard Protection: Foam
Keyboard package dimensions: 530 x 168 x 43 mm
Keyboard package weight: 646 gr