

UNIMOUSE

Wired

Product Manual



contour 

Box Contents

1. Unimouse
2. User Guide



Unimouse Functions



For additional mouse features and specific Mac settings, please download our driver at contourdesign.com/support

*see page 4

Connecting to a Computer

Plug the Unimouse into the computer's USB port. Allow your computer a few seconds to automatically install the mouse drivers.



Middle Click to Double Click

Unimouse comes with middle click as the default setting. To change the middle click function to double click, hold down the cursor speed button and the middle click button at the same time. To switch back, repeat the same command.

Middle click / Double click




Cursor speed (DPI)



Adjustable Features

Unimouse has 4 key points of articulation. We encourage you to explore a variety of positions while using your Unimouse. For more details regarding adjustability, please refer to the Adjustability Guide.


The thumb rest can be extended or collapsed to accommodate different hand sizes.



Slide the thumb support forward or back to accommodate variations in thumb length and grip preference.



Adjust tilt for your desired mousing angle.



The thumb support can be rotated in any direction to adjust to your preferred thumb position.

Change Cursor Speed

Press the cursor speed button to cycle through cursor speeds. There are ten speed selections ranging from slow (800 DPI) to fast (2800 DPI). Speed is indicated by the LED lights as shown.

