


## OysterMouse Instructions

### Get started:

Understand the mechanical functions before using your OysterMouse. Open the OysterMouse to a position you find comfortable. If you want to close the mouse or reduce the angle, first open to *released position* (see illustration to the right).


### Connecting the OysterMouse:

Connect your OysterMouse to an USB port on your computer. The OysterMouse is compatible with Windows up to Win7. The copy/paste functions are not supported on a Mac.



In order to close the mouse FIRST OPEN to *released position*! If too much force is used when pressing the top of the mouse down without releasing mechanism first, the joint might break. In this case damage is not covered by warranty.  
**Warranty does NOT cover misuse.**

## Switch Mode



## Button functions

### Right hand



### Left hand



### Right and left hand mode



**ergoption**  
OysterMouse manual

