

## Manuel d'utilisation BarMouse

### Connecting your BarMouse:

Connect your BarMouse to one of the computer's USB ports.  
No driver is required.

### Bar cover:

The cover at the right side of the bar can be removed in order to expose more of the roller-bar. Put the cover back on if you accidentally hit the bar when typing. When roller-bar is adjusted to the appropriate level, the cover should not be needed.

### Wrist rests:

The wrist rests can easily be taken off (pull straight up). There are different models of wrist rests that can be used, as shown on the front of box. The wrist rests can be washed with soap and water (after have been removed from the product).

### Using your BarMouse:

- Position the BarMouse with the scroll wheel, centrally located in front of the keyboard-spacebar.
- Rotate the bar to move the cursor up or down. Slide it sideways to move the cursor left or right. Press the bar down to get "left mouse-click".
- If the bar comes to a horizontal end position, then press the bar slightly in the blocked direction, resulting in a click sound and the cursor will continue moving in the desired direction.

