

## Lapmate

### Instructions

Press the gray button located at the center of the hinge that you want to adjust and select the desired angle. Release the button to lock the hinge. Repeat the operation on each hinge until you have obtained the desired setting for your tray.

Sit comfortably and place the Lapmate over your legs if you are sitting, or over your pelvis if you are lying. Put your laptop on the tray.

### Settings

We suggest the following angles adjustments:

#### 1 / Low position on sofa

- External articulation: 0°
- Central articulation: -30°
- Internal articulation: -60°

#### 2 / High position on sofa

- External articulation: -15°
- Central articulation: -30°
- Internal articulation: -45°

#### 3 / Max stability position on sofa

- External articulation: 180°
- Central articulation: -45°
- Internal articulation: -150°

#### 4 / Low position on bed

- External articulation: 0°
- Central articulation: -30°
- Internal articulation: -75°

#### 5 / High position on bed

- External articulation: -15°
- Central articulation: -30°
- Internal articulation: -60°

#### 6 / Max stability position on bed

- External articulation: 180°
- Central articulation: -45°
- Internal articulation: 180°

#### 7 / Breakfast tray position on bed

- External articulation: 0°
- Central articulation: 90°
- Internal articulation: -90°

#### 8 / Side table position for sofa and bed

- External articulation: -90°
- Central articulation: 180°
- Internal articulation: -90°

#### 9 / Tilted tray on desk position

- External articulation: 0°
- Central articulation: 0°
- Internal articulation: -45°

Of course, you can also adjust the angle to your liking and create your own positions!

### Precautions

The maximum load of Lapmate is **15 kg / 33 lbs**. Remove your laptop from the Lapmate when you change its position. Do not exert side pressure on the hinges. Handle your Lapmate carefully to avoid pinching or cutting.