



Web: www.zenlap.com
Email: contact@zenlap.com
Phone: +33 977 195 030

Lapmate Fit

Instructions

Press the gray button located at the center of the hinge that you want to adjust and select the desired angle. Release the button to lock the hinge. Repeat the operation on each hinge until you have obtained the desired setting for your tray. Lift out the retractable stopper to wedge your computer.

If you wish to use the retractable mouse tray, unscrew with one revolution the two screws of the tray, which are situated below the Lapmate Fit. Then pull out the mouse tray.

Sit comfortably and place the Lapmate Fit over your legs if you are sitting, or over your pelvis if you are lying. Put your laptop on the tray.

Settings

We suggest the following angles adjustments:

1 / Position on sofa

- External articulation: -30°
- Internal articulation: -60°

2 / Position on bed

- External articulation: -30°
- Internal articulation: -75°

3/ Tilted tray on desk position

- External articulation: 0°
- Internal articulation: -45°

Of course, you can also adjust the angle to your liking and create your own positions!

Precautions

The maximum load of Lapmate Fit is **10 kg / 22 lbs**. Remove your laptop from the Lapmate when you change its position. Do not exert side pressure on the hinges. Handle your Lapmate carefully to avoid pinching or cutting.